


1. Setup of Serial Port (M62) ,as shown below:



2. Connect flow meter to RS485 conversion module .




3. Select Communication Protocol (M63)



4. Set parameters in software, and then click OK





5. Connection is successful .

